




**JAMES BARONE RACING**

## **2007 - 2009 MAZDASPEED 3 JBR TRU 3" AND 3.5" ALUMINUM WIDE PATH INTAKE SYSTEM INSTALLATION INSTRUCTIONS**


### **Tools Required:**

Socket wrench  
10mm Deep Socket  
Socket Extension  
Regular Pliers  
Needle Nose Pliers  
Medium Philips Head Screwdriver  
3mm Allen Wrench


- Be sure to have you AccessPort handy and a map prepared with the proper MAF calibration before proceeding or your car will not run correctly.
  - It is important to **Read** and **Understand** the instructions thoroughly before getting started. Take note of, and **follow** the tips in red found throughout the instructions.
1. Using a 10mm socket remove the two 10mm bolts securing the intercooler cover. Then slide the cover towards the rear of the vehicle and remove.



2. Using a philips head screwdriver loosen the clamp securing the intake tube to the top of the factory air box. Then remove the connection to MAF sensor by squeezing the tab and pulling the connector off.



3. Unclip the fasteners securing the top the air box to the bottom



4. Lift the top of the air box up, push the intake hose off and remove the top of the air box from the vehicle.



5. Squeeze and remove the clip shown below.



6. Slide the rubber fastener towards the rear of the vehicle.




7. Remove the rubber band shown below.




8. Tug up on the bottom of the air box and remove it from the vehicle.




9. Remove the battery box cover and ECU cover. There are tabs on either side of the battery box and a tab on the front and two on the side of the ECU cover.




- Using a 10mm socket remove the battery hold down bracket, the negative battery terminal connection, then the positive connection.



- Using a pair of needle nose pliers remove the fasteners securing the wiring harness to the front cover of the battery box. There are two on the outside and one inside. Slide the front cover of the battery box up and remove from the vehicle. Remove the battery.



12. Remove the three 10mm bolts in the bottom of the battery box.



13. Disconnect the wiring harness from the ECU by pressing the tab below the white handle. Then lift the handle to remove the connector. Remove the battery box and ECU as one assembly from the vehicle.




14. Remove the two 10mm nuts securing the wiring harness bracket. Lift the bracket off the studs and lay wiring harness over towards the front driver's side so it's not in your way.




15. Using a pair of needle nose pliers, squeeze the clamp on the boost control solenoid vacuum hose and slide it up. **VERY, VERY CAREFULLY** twist the hose to loosen it from the boost control solenoid and remove the hose. Using a philips head screwdriver, loosen the clamp securing the intake hose to the turbo inlet.


- Failure to remove the vacuum hose carefully could result in breaking the hose nipple off, quickly ruining your day.



16. Use a pair of pliers to squeeze the clamp securing the bypass hose to the turbo inlet pipe and slide it towards the front of the vehicle, then remove the bypass hose from the turbo inlet pipe. Using a 10mm socket remove nut circled below. Using a pair of needle nose pliers, remove the 2 fasteners securing the wiring harness to the turbo inlet pipe.




17. Disconnect the valve cover breather connection from the 90 degree fitting in the intake hose by squeezing both blue tabs together then pulling up. Remove the opposite end of the valve cover breather hose from the valve cover the same way. Then remove the intake hose and turbo inlet pipe as one assembly from the vehicle.



18. Install the turbo inlet coupler on to the turbo using the included T-bolt clamp appropriate for your application. Tighten the turbo side T-bolt clamp with a 10mm socket and add on the appropriate clamp for your intake as shown below.



19. Next remove the OEM rubber grommet used to secure the OEM turbo inlet pipe the motor and install it on to your new intake.



20. Install the intake in to the turbo inlet coupler and over the mounting stud. Tighten the T-bolt clamp at the turbo inlet coupler and secure the intake with the 10mm nut removed in step 16 using a 10mm socket.



21. Install the included boost control solenoid vacuum line on to the intake and the boost control solenoid.

➤ No clamps are required for these connections



22. Cut approximately 6" off the 5/8" silicone hose included with your kit and install the 90 degree barbed adaptor on to one end. Add the remaining hose to the other leg of the 90 degree barbed adaptor. Install the long hose on to the valve cover vent and the short end on to the intake adjusting the length of the hoses as needed.

➤ No clamps are required for these connections.



23. Reconnect the bypass hose removed in step 16.

➤ Depending on your intercooler set up, the bypass hose may fit better if installed in the reverse direction.



24. Remove the MAF sensor from the factory air box using a philips head screw driver.




25. Install the MAF sensor using the included screws and tighten with a 3mm allen wrench. Install the JBR Dry Flow Filter and MAF coupler and secure both with the included T-bolt clamps as shown and tighten with a 10mm socket.




26. Add the remaining T-bolt clamp included with your kit to the end of the MAF coupler and slip the MAF housing and filter assembly on to the intake. Adjust the MAF housing and filter assembly as needed and tighten the T-bolt clamp with a 10mm socket.



27. If you're installing the 3.5" intake remove the ECU cover, ECU and ECU mounting bracket from the battery box with a philips head screw driver and 10mm socket. Reinstall the OEM battery box and battery.
- The ECU can be relocated to the top of the fuse box with some 3M two side tape or for a cleaner look install a JBR 51R Small Battery Box.
  - The 3" intake only requires the ECU cover to be removed and no ECU relocation is necessary.





28. Reconnect the ECU and MAF sensor connections

**Congratulations!! You've just completed the installation of your JBR All Aluminum Wide Path Intake System!!**

## **SHIPPING**

All orders are carefully inspected and packaged prior to shipment. The recipient must inspect all shipments for damage and report any damage to the carrier and JAMES BARONE RACING immediately. JAMES BARONE RACING is not responsible for damage that occurs during shipping.

## **RETURNS:**

All sales are final. JAMES BARONE RACING will only except returns in the event of a manufacturer's defect. Defective items will be exchanged for the identical item or repaired at our discretion. Return shipping costs are the responsibility of the purchaser. An RMA # (Return to Manufacturer Authorization Number) Must accompany all returns. In rare cases where a return is accepted a 15% restocking fee will be deducted from the refund or credit. Shipping charges are non- refundable. No returns or exchanges will be accepted after 30 days.

## **DISCLAIMERS:**

Failure to carefully follow the installation instructions for your JAMES BARONE RACING product could result in significant property damage, personal injury, injury to others or even death. Please take the time to read and thoroughly understand the instructions prior to installation. The instructions are as accurate as possible and may vary slightly from model year to model year. Professional installation is recommended. Neither JAMES BARONE RACING nor any of its employees, officers, directors, or shareholders will accept responsibility for improper use or installation of our products. JAMES BARONE RACING is not responsible for the misuse, incorrect installation, or failure of any product we sell. Under no circumstances, including but not limited to negligence, will JAMES BARONE RACING be liable for special or consequential damages that result from the use or inability to use our products. JAMES BARONE RACING does not assume responsibility for any damage to the user, driver, passenger or vehicle resulting from the operation of a JAMES BARONE RACING product. PLEASE DRIVE RESPONSIBLY.

## **WARRANTY:**

All JAMES BARONE RACING products carry a lifetime warranty to the original purchaser. Warranty is non-transferable. Warranty does not cover damage or failure caused by abuse, misuse, faulty installation or repairs not conducted by JAMES BARONE RACING. JAMES BARONE RACING is not liable for consequential damages arising from the use of our products or any indirect damages resulting in the loss of property, revenue or costs for towing, removal, installation, or re-installation. To receive warranty service you must contact JAMES BARONE RACING to receive an RMA # (Return to Manufacturer Authorization Number) at which time you will be provided with instructions for returning the faulty product

## **CONTACT:**

If you have questions or problems, e-mail us at [jamesbaroneracing@gmail.com](mailto:jamesbaroneracing@gmail.com). Posting questions or problems in the forums or other social media outlets will only delay you from getting the correct answer or personalized attention from us.